



TransitLock

SECURE YOUR FLEET

TransitLock is a combination of encrypted software and hardware which can lock a vehicle from coming out of gear and can be used in combination with TransitCheck. TransitCheck software allows an Android tablet or phone to unlock a vehicle so it can come out of gear when the driver enters an ID and password, or uses an encrypted (RFID) badge. Once verified, the TransitLock software sends an encrypted wireless signal to the TransitLock hardware to unlock the vehicle. This allows drivers to leave their vehicle idling, without concern that someone may steal it such as when allowing vehicle cool down, when the driver is out assisting a passenger, or when the driver takes a break. Secure your fleet! Install TransitLock today!

E-MAIL FOR A NO OBLIGATION ON-LINE DEMONSTRATION

lock@transit-check.com



TRANSITLOCK FEATURES



Easy to Use

Any authorized driver can unlock any vehicle in the fleet with a tablet or phone, and their ID and password, or an RFID card. The authorization to unlock vehicles can be removed almost instantly from the management web portal at any time – for instance, when a driver is terminated.



Operational Security

The system is designed so drivers can leave a vehicle to put out a wheel chair lift or take a bathroom break, and still let the vehicle idle. If the driver forgets, there is assured automatic locking -- it will auto re-lock after a short set time.



Risk Reduction Safety Improvement

With TransitLock an agency's theft risk is reduced. No longer will management have to fret over anyone other than an authorized driver taking or driving the vehicle at any time



Vehicle Flexibility

TransitLock hardware can perform the demanded lock function in virtually any vehicle. The hardware is designed to interrupt the gear shift signal to prevent the vehicle from coming out of gear.



TransitCheck Flexibility

Since the TransitCheck App permits any Android tablet or phone to inspect any vehicle, the implementation of TransitLock within TransitCheck provides that any authorized driver can also operate TransitLock on any equipped vehicle.



TransitLock Flexibility

Modules are easily paired with the vehicle they are installed in. If the hardware ever is removed or changed, re-authorizing TransitLock is simple.




Implementation Flexibility

TransitLock is simple to install and can be installed in Factory, at a Dealer or Post Delivery while in your fleet.



Simple User Interface

Simple for driver to operate and very intuitive, there is little training required. If there is ever an issue, a manual override can be installed.



© COPYRIGHT 2019 REVECORP INC.